O.A. PLAN N.T.S. FRONT ELEVATION BACK ELEVATION N.T.S. N.T.S. (4) 5'-0" ABOVE GRADE 3'-0" BELOW GRADE -(12) -(13) (14)

FRONT ELEVATION/SECTION

KEY

- (1) SET TREE PLUMB IN PLANTING PIT.
- 2 PROTECT TREE TRUNK WITH I NOMACO® STYROFOAM PADDING GUARDS, #6U048048, AS SPECIFIED, OR APPROVED EQUAL.
- (3) AMAZON HOUSE AND RUBBER®. I ¼ AIR HOSE #kII46 OR APPROVED EQUAL, TO COVER 10 GAUGE WIRE.
- 4 I IO GAUGE GALVANIZED WIRE. WIRE PRODUCT®, OR APPROVED EQUAL.
- (5) I 2"x4"x4' NON TREATED LANDSCAPE TIMBER AS SPECIFIED. FASTEN WITH 4 3½" DECK SCREWS TO 2"x4"x8' P.T. LANDSCAPE TIMBERS.
- (6) I & MALLEABLE CLAMP FASTENER FOR WIRE. SUPPLIER: FLORIDA WIRE ® OR APPROVED EQUAL.
- 7) 2 2"x4" X 8' P.T. LANDSCAPE TIMBER AS SPECIFIED.
- (8) I"-2" MULCH DEPTH LAYER ON ROOT BALL.
- 4" WATER RING, (WITHIN ROOTBALL DIA.), FILL 3 TIMES IMMEDIATELY AFTER PLANTING, RAKE OUT PRIOR TO MULCHING AND PLANTING.
- (10) ROOT FLARE 1"-2" ABOVE FINISHED GRADE.
- (I) B&B OR CONTAINERIZED ROOTBALL. REMOVE ALL BURLAP IF NOT 100% BIODEGRADABLE. REMOVE CONTAINER FROM ROOTBALL PRIOR TO PLANTING.
- (2) BACKFILL. TOP SOIL TYP. OF AREA. BACKFILL SHALL BE AMENDED THROUGHOUT ENTIRE SITE WITH FERTILIZER AND COMPOST AS REQUIRED.
- (13) UNDISTURBED SUBGRADE.
- (4) COMPACT SOIL IMMEDIATELY BENEATH THE ROOT BALL TO PREVENT SETTLING.

NOTES :

- I. CONTRACTOR TO ASSURE PERCOLATION IN TREE PITS.
- 2. NO MULCH WITHIN 4" OF TRUNK.